

UNLOADING EQUIPMENT!

WWW.SIMPASUS.COM



The following photos outline the equipment you will want for Receiving and unloading windows.



01

**TELESCOPING
FORKLIFT**



1 + plus

02

**FORK
EXTENSIONS**



8 pieces

03

**INDUSTRIAL STRENGTH
RATCHET & STRAPS**



**6 ratchet straps
4 strength straps**

04

SAWZALL



1 + plus

05

SKILSAW



1 + plus

06

**CORDLESS
DRILLS**



3 pieces (18v)

07

**T20 AND T25
TORX BITS**



1 + plus (Set)

08

**PHILLIPS
BITS**



1 + plus (Set)

09

**FLAT
BARS**



3 pieces

10

**CROW
BARS**



3 pieces

11

**PALLET
JACK**



1 pieces

12

**SUCTION CUPS FOR
HANDLING THE GLASS**



6-8 pieces

RECEIVING

Your **Simpas** Windows and Doors will be shipped to your jobsite location on a shipping container. Your windows and doors will be carefully packaged, and packed into the container at the factory in Europe.

The container is picked up from the factory via truck, transported to a port and loaded on a ship for its journey across the ocean. Once the container arrives in the USA, it will either be placed on a train, or a truck to be delivered to your jobsite. The size of your container will either be 20' long or 40' long, so clear access to the jobsite is important. If your jobsite will not allow for a semi-truck with a 40' container to safely deliver your order, you will want to offload at a safer location and transport the windows and doors to the jobsite using a large moving truck.

The amount of time it takes to transport your order depends on the location of delivery in the USA.

Shipping times vary between 5-10 weeks.



**Live
Better.**

**Please call or email us if
you have questions about
receiving and unloading.**



THANK YOU

LET'S DISCUSS

WWW.SIMPASUS.COM

